


## Export ForeCytData into FlowJo



To show the wells simply right click on the header bar in the FlowJo workspace. Choose 'edit columns'. From the left scroll-down menu choose 'file name' and move to the right column and then the top of the list by dragging and dropping. Also be aware that the each axis for the dot plots must be optimized for scaling by clicking on the large "T" at the terminus of each dotplot. Then adjust the +/- to scale appropriately. At this time biexponential may be chosen as well. NB that this may improve the appearance of all data but biexponential will work best on data generated on ForeCyt V. 5.1 or later.

